

Sturmgepäck

The following steps illustrates one method for preparing the Zeltbahn/Mantelrolle for the Sturmgepäck:

1. Lay out *Zeltbahn* (shelter half) with the inside up, the center seam running vertical, and the neck chord loops at the top. Place the *Mantelrolle* (Overcoat roll) at the bottom edge and centered on the center seam.



2. Fold the ends of the *Zeltbahn* over the *Mantelrolle* ends.

3. Roll the *Manterolle* up in the *Zeltbahn*.



The following steps demonstrate one method for preparing the *Zeltbahn/Decke* (Blanket) roll for the *Sturmgepäck*:

4. Lay out *Zeltbahn* (shelter half) with the inside up, the center seam running vertical, and the neck chord loops at the top.



5. Place the blanket on top, aligning the top edge with that of the *Zeltbahn*.

6. Fold the bottom end of the blanket up so that it is within the bottom edge of the *Zeltbahn*. Fold the ends of the *Zeltbahn* and blanket over a few inches on sides.



7. Roll the *Zeltbahn* and blanket tightly from the bottom toward the top.



Now that the *Zeltbahn/Mantelrolle* or the *Zeltbahn/Decke* roll have been created, the following steps will be the same for either.

8. Buckle one *Kochsgeschirriemen* (Messkit strap) in the center of the roll (the top of the pack).
9. Lay the Messkit with the lid toward the top and wrap the *Zeltbahn*/blanket roll down the sides of the messkit. Buckle (2) *Mantelriemen* at points roughly in the middle of Messkit with the auxiliary strap ends pointing away from the Messkit.
10. Loop the *Mantelriemen* ends through the Messkit bail and attach to their studs.



11. Flip the assembly over and loop a *Brotbeutelriemen* (Breadbag strap) through the *Kochsgeschirriemen* strap at the top of the pack. Pull the *Zeltbahn/blanket* roll ends together and buckle a *Kochsgeschirriemen* making sure that the buckle is centered. Hook the ends of the *Brotbeutelriemen* to the buckle. The pack is now complete.



Note: If one breadbag strap does not provide enough length to slip your arms through, rotate the strap at the top so the buckle is visible on the same side as the bottom strap. Hook one end of each *Brotbeutelriemen* to the top buckle and the other end to the bottom buckle.